

ASSEMBLY PROCEDURE CHANGE NOTICE

Reference Paragraph 4.6.2, Step 6 on Page IV-5 in Section IV of the Sol-PC Single Board Terminal ComputerTM Assembly and Test Instructions.

The PM5204 Personality Module Kit you have received with your Sol-PC Kit includes 2 each 2-56 x 3/16 binder head screws, 2 each #2 inside tooth lockwashers and 2 each 2-56 x 3/16 (max) hex nuts. These are used to attach the handle bracket (Sol-1045) to the PM5204 circuit board.

With your kit, use the following procedure to attach the handle bracket in place of Step 6 in Paragraph 4.6.2, Section IV: (Figure 4-2 on Page IV-5 in Section IV may still be used for reference concerning the position of the bracket.)

Position handle bracket (Sol-1045) on front (component) side of the board at the right end as shown in Figure 4-2. Align bracket holes with mounting holes in board, insert screws from back (solder) side of board, place lockwasher on each screw, start nuts and tighten.

CC #1