

PROCESSOR TECHNOLOGY CORP.
6200 HOLLIS STREET
EMERYVILLE, CALIF. 94608

C071	7E	0211	DISPT	MOV	A,M	GET LOW BYTE
C072	23	0212		INX	H	
C073	66	0213		MOV	H,M	AND THE HIGH
C074	6F	0214		MOV	L,A	WE HAVE PLACED THEM BOTH
C075	E9	0215		PCHL	.	GO TO IT
C076		0216	*			
C076	23	0217	*			
C076	23	0218	NEXT	INX	H	GO TO NEXT
C077	23	0219		INX	H	
C078	C3 62 C0	0220		JMP	TSRCH	
C078		0221	*			
C078		0222	*			
C07B	78	0223	CHAR	MOV	A,B	GET CHARACTER
C07C	B7	0224		ORA	A	
C07D	C8	0225		RZ	.	RETURN IF A NULL
C07E	FE 7F	0226		CPI	7FH	IS IT A DEL?
C080	C8	0227		RZ	.	GO BACK IF SO
C081		0228	*			
C081		0229	*			
C081		0230	*			
C081	CD 21 C1	0231	OCHAR	CALL	VDADD	GET SCREEN ADDRESS
C084	78	0232		MOV	A,B	GET CHARACTER FOR OUTPUT
C085	E6 7F	0233		ANI	7FH	NO HIGH BITS GO PAST HERE
C087	77	0234		MOV	M,A	PUT CHR ON SCREEN
C088	3A 00 C8	0235		LDA	NCHAR	GET CHARACTER POSITION
C08B	FE 3F	0236		CPI	63	END OF LINE?
C08D	DA AD C0	0237		JC	OK	
C090	3A 01 C8	0238		LDA	LINE	
C093	FE 0F	0239		CPI	15	END OF SCREEN?
C095	C2 AD C0	0240		JNZ	OK	
C098		0241	*			
C098		0242	*			END OF SCREEN...ROLL UP ONE LINE
C098		0243	*			
C098	AF	0244	SCROLL	XRA	A	BACK TO FIRST CHAR POSITION
C099	32 00 C8	0245		STA	NCHAR	
C09C	4F	0246		MOV	C,A	
C09D	CD 28 C1	0247	SROL	CALL	VDAD	CALCULATE LINE TO BE BLANKED
C0A0	AF	0248		XRA	A	CLEAR IT
C0A1	CD E9 C0	0249		CALL	CLINI	
C0A4	3A 02 C8	0250		LDA	BOT	
C0A7	3C	0251		INR	A	
C0A8	E6 0F	0252		ANI	0FH	
C0AA	C3 DD C0	0253		JMP	ERAS3	
C0AD		0254	*			
C0AD		0255	*			INCREMENT LINE COUNTER IF NECESSARY
C0AD		0256	*			
C0AD	3A 00 C8	0257	OK	LDA	NCHAR	GET CHR POSITION
C0B0	3C	0258		INR	A	
C0B1	32 00 C8	0259		STA	NCHAR	STORE THE NEW
C0B4	FE 40	0260		CPI	64	
C0B6	D8	0261		RC		
C0B7	AF	0262		XRA	A	WE'RE PAST THE END... REWIND THE COUNT
C0B8	32 00 C8	0263		STA	NCHAR	