

Sol-BPB

REVISION LEVEL B BOARDS ONLY



ASSEMBLY PROCEDURE CHANGE NOTICE #5

Reference Section VI, Step 4, Page VI-8

On some Rev B boards, the blue and two white leads on the cable are too large for the mounting holes. To overcome this problem, prepare these three leads as follows:

1. Cut off end of white and blue wires, about 1/8" back into insulation.
2. Cut off as many strands of each wire as needs in order to insert through mounting hole.

CN#5A