

ASSEMBLY PROCEDURE CHANGE NOTICE #5Reference Section VI, Step 4, Page 5

When attaching the cable to the Sol-BPB, insert wires from solder (back) side of board and solder on component (front) side.

NOTE

Pad orientations given in Step 4 are as viewed from component side of board.

The blue and two white leads on the cable are too large for the mounting holes. To overcome this problem, prepare these three leads as follows:

1. Cut off end of white and blue wires, about 1/8" back into insulation.
2. Cut off as many strands of each wire as needed in order to insert through mounting hole.