

Destination

Europe except France, Asia, South America	USA, Canada	Japan	Ref. No.	Part code	Description	Remarks
			1-1	5MVB996SH005	COVER FRONT	
			1-2	5MVS428AM001	PLATE ECOSYS	
			1-2	5MVS428AM002	PLATE ECOSYS	
			1-3	5MMS627SW001	PLATE MAGNET CATCH	
			1-4	5AAY7000E*54	HINGE FRONT LA	
			1-5	5AAY7000E*55	HINGE FRONT LB	
			1-6			
			1-7			
			1-8	5AAY7000E*59	COVER PANEL E ASSY	English
			1-8	5AAY7000E*60	COVER PANEL G ASSY	German
			1-8	5AAY7000E*61	COVER PANEL F ASSY	French
			1-8	5AAY7000E*62	COVER PANEL S ASSY	Spanish
			1-8	5AAY7000E*63	COVER PANEL I ASSY	Italian
			1-8	5AAY7000E*64	COVER PANEL D ASSY	Danish
			1-8	5AAY7000J*10	COVER PANEL J ASSY	Japanese
			1-9	5MVS647AM001	LENS PANEL A	Part of 1-8
			1-10	5MVS669AM001	COVER PANEL B	Part of 1-8
			1-10	5MVS668AM002	COVER PANEL J	Part of 1-8
			1-11	5MVX755SH001	COVER PANEL L	
			1-11	5MVX755SH003	COVER PANEL LJ	
			1-12	5MVX755SH002	COVER PANEL R	
			1-13	5AAVBRCKT057	BKT RIGHT ASSY	
			1-14	5MMB986SM003	COVER REAR	Part of 1-61
			1-15	5MML782SM001	COVER MAIN	Part of 1-61
			1-16	5MVB986SH025	LID TOP	Part of 1-23
			1-17	5MVB661SH005	STOPPER PAPER	Part of 1-23
			1-18	5MVB772SH009	COVER STOPPER	Part of 1-23
			1-19	5MVX621DW002	LOCK COVER	Part of 1-23
			1-20	5MVX664DH001	PLATE TOWER	Part of 1-23

Shaded: Part used for the destination

FS-7000/LS-7000

Destination

Europe except France, Asia, South America	USA, Canada	Japan	Ref. No.	Part code	Description	Remarks
			1-21	5MVX997SH001	COVER TOP	
			1-22		RUBBER FRONT B	
			1-23	5AAVCOVER185	LID TOP ASSY	
			1-23	5AAVCOVER191	LID TOP J ASSY	
			1-24	5AAY7000E*28	KEY BOARD ASSY	
			1-25	5MMX761SL003	BRACKET FAN	
			1-26	5EZN2402501*03	FAN MOTOR	
			1-27	5MVX421DH003	LOCK LID TOP F	
			1-28	5MVX643DH001	LOCK LID TOP R	
			1-29	5MVX853DG001	LEVER TOP	
			1-30	5MMW465LD001	SPRING CONT A	
			1-31	5MVB322DB001	PUSH CONTAIN	
			1-32	5MVB862SH012	PANEL FRONT	Part of 1-24
			1-33	5MVX642SH008	BUTTON KEY L	Part of 1-24
			1-34	5MVX642SH009	BUTTON KEY R	Part of 1-24
			1-35	5MVS639RF005	SEAL LCD	Part of 1-24
			1-36	5AAPRKBC2002AH	P.W. BOARD ASSY	Part of 1-24
			1-37	5AAY7000E*47	TRAY FU ASSY	
			1-38	5MMX321SM001	CORD KEEP	Part of 1-37
			1-39	5MVX872SW001	TRAY FU B	Part of 1-37
			1-40	5MVX761SW001	TRAY FU C	Part of 1-37
			1-41	5MMX842SN002	PLATE TRAY F	Part of 1-37
			1-42	5MMX842SN003	PLATE TRAY R	Part of 1-37
			1-43			
			1-44	5MVX721CW001	LINK FU F	Part of 1-37
			1-45	5MVX721CW002	LINK FU R	Part of 1-37
			1-46	5MVX521SW007	HINGE FU F	Part of 1-37
			1-47	5MVX521SW008	HINGE FU R	Part of 1-37
			1-48	5MDX321DN011	SLIDER FU	Part of 1-37

Shaded: Part used for the destination


FS-7000/LS-7000

Destination

Europe except France, Asia, South America USA, Canada Japan	Ref. No. Part code		Description	Remarks
	1-49	5MVS422XF002	SEAL ECOSYS	
	1-50	5MVS642XF005	SEAL PANEL A	Part of 1-8
	1-51	5MVB722SW001	BKT TRAY FA	Part of 1-37
	1-52	5MVB722SW002	BKT TRAY RA	Part of 1-37
	1-53	5MVB622SW002	BKT TRAY FB	Part of 1-37
	1-54	5MVB622SW003	BKT TRAY RB	Part of 1-37
	1-55	5AACCNQB1GEA	CONN CORD S02057	
	1-56	5KKT7000E*QX	SHEET OPE. MANUAL	
	1-56	5KKT7000J*QX	SHEET OPE. MANUAL	
	1-57			
	1-58	5MVVL662GE33	LABEL DIAGRAM A	Part of 1-23
	1-58	5MVVL662GE35	LABEL DIAGRAM A	Part of 1-23
	1-59	5MVVL762GE15	LABEL DIAGRAM B	Part of 1-23
	1-59	5MVVL762GE16	LABEL DIAGRAM B	Part of 1-23
	1-60	5MVVL662GE34	LABEL DIAGRAM C	Part of 1-23
	1-61	5AAVCOVER188	COVER REAR ASSY	
	1-62	5MVX985SW001	COVER LEFT	
	1-63	5MVB984SW005	COVER RIGHT	
	1-64	5MVQ222RB005	RUBBER FRONT	

Shaded: Part used for the destination

FS-7000/LS-7000



Destination

Europe except France, Asia, South America USA, Canada Japan	Ref. No.	Part code	Description	Remarks
	2-1	5AACCNQA6GEA	CONN CORD ASSY	
	2-2	5AACCNQA7GEA	CONN CORD ASSY	
	2-3	5AACCNQA9GEA	CONN CORD ASSY	
	2-4	5AACCNQB0GEA	CONN CORD ASSY	
	2-5	5AACCNQC0GEA	CONN CORD ASSY	
	2-6	5AACCNQC2GEA	CONN CORD ASSY	
	2A-1	5MVB976CB002	FRAME FRONT	
	2A-2	5MVF775SB001	ARM LEVER DLP	
	2A-3	5MVN754SG001	LEVER DLP A	
	2A-4	5MVX543DN001	LEVER DLP B	
	2A-5	5MMW576LD001	SPRING LEVER A	
	2A-6	5MVX753DG001	LEVER DRUM	
	2A-7	5MVX432DB008	LOCK DRUM	
	2A-8	5MMW566LD002	SPRING LEVER DRUM	
	2A-9	5MVX643SB008	BKT PWB	
	2A-10	5MMW465LD002	SPRING LOCK DRUM	
	2A-11	5MVX766SB014	GUIDE DLP REAR	
	2A-12	5MVL854SB002	TRAY RAIL	
	2A-13	5MVL655SB001	RAIL DLP F	
	2A-14	5MMB965SD001	RAIL DLP	
	2A-15			
	2A-16	5AAPRSWC1007AH	P.W. BOARD ASSY	
	2A-17	5AAPRIFC1017AH	P.W. BOARD ASSY	
	2A-18	5AACCNQC1GEA	CONN CORD ASSY	
	2A-19	5AACCNQC9GEA	CONN CORD ASSY	
	2A-20	5AACCNQE8GEA	CONN CORD ASSY	
	2A-21	5MMC834SD001	PLATE FRAME SIDE	

Shaded: Part used for the destination

FS-7000/LS-7000

Destination

Europe except France, Asia, South America	USA, Canada	Japan	Ref. No. Part code	Description	Remarks
			2A-22 5MMC933SD001	PLATE FRAME	
			2A-23 5AAVMGNET005	MAGNET CATCHER	
			2B-1 5MVX987CB001	FRAME REAR	
			2B-2 5MMC764LD001	PLATE CON A	
			2B-3 5MVX643DB003	ACTUATOR JOINT	
			2B-4 5MMW176LD001	SPRING JOINT	
			2B-5 5MMP433LD002	PLATE BIAS	
			2B-6 5MVB533SB005	COVER PWB CONT	
			2B-7 5MMM311SZ001	PIN HV CONTACT	
			2B-8 5MMW311LD003	SPRING HV CONTACT	
			2B-9 5MVB632SB009	COVER CONTACT	
			2B-10 5MMW605LD002	SPRING MAIN A	
			2B-11 5AAXRD016GEA	HIGH MEG R ASSY	
			2B-12 5ENZNF2403202*01	FAN MOTOR	
			2B-13 5MVZ641LD001	PLATE DRUM PWB	
			2B-14 5ENXGP1A73A**01	PHOTO SENSOR	
			2B-15 5MVX874SB003	CASE BELT GUIDE	
			2B-16 5AAY7000E*46	TOWER SENSOR ASSY	
			2B-17 5MVX552SB006	INTERRUPT SENSOR	
			2B-18 5MMW172SD001	SPRING SENSOR	
			2B-19		
			2B-20		
			2B-21 5AAPRZZC1048BH	P.W. BOARD ASSY	
			2B-22 5AAPRIFC1016AH	P.W. BOARD ASSY	
			2B-23 5AAPRIFR2004AH	P.W. BOARD ASSY	
			2B-24 5AACCNQA8GEA	CONN CORD ASSY	
			2B-25 5AACCNQC4GEA	CONN CORD ASSY	

Shaded: Part used for the destination

FS-7000/LS-7000

Destination

Europe except France, Asia, South America USA, Canada Japan	Ref. No. Part code		Description	Remarks
	2B-26	5AACCNQC6GEA	CONN CORD ASSY	
	2B-27	5AACCNQC7GEA	CONN CORD ASSY	
	2B-28	5AACCNQD0GEA	CONN CORD ASSY	
	2B-29	5AACCNQD1GEA	CONN CORD ASSY	
	2B-30	5AACCNQD2GEA	CONN CORD ASSY	
	2B-31	5AACCNQD3GEA	CONN CORD ASSY	
	2B-32	5AACCNQD4GEA	CONN CORD ASSY	
	2B-33	5AACCNQD5GEA	CONN CORD ASSY	
	2B-34	5AACCNQD6GEA	CONN CORD ASSY	
	2B-35	5AACCNQF4GEA	CONN CORD ASSY	
	2B-36	5MVU666SB001	DUCT DRUM	
	2B-37	5MVQ222XX001	CORD PRESS	
	2B-38	5MMM140SZ011	COLLAR SPACER	
	2B-39	5MMM340SZ002	COLLAR SPACER	
	2B-40	5MVQ211EF001	SPONGE MAIN	
	2B-41	5MVS632KF009	SHEET FAN A	
	2B-42	5AAXTR037VDA	TRANS ASSY	
	2B-43	5MVS321KN013	SHEET TONER	
	2B-44	5AAPRSSC1016AH	P.W. BOARD ASSY	
	2B-45	5MMX321SM001	CORD KEEP	US scanner
	2C-1	5MMC962SD001	BASE STAY L	
	2C-2	5MMC962SD002	BASE STAY R	
	2C-3	5MMB993SD001	PLATE BASE LID	
	2C-4	5MMC834SD001	FRAME BASE ASSY	
	2C-5	5MMC933SD001	FRAME BASE ASSY	
	2C-6	5MMX653LD002	PLATE EARTH FRONT	
	2C-7	5MVX832SH006	COVER FRONT LOW L	
	2C-8	5MVX832SH007	COVER FRONT LOW R	

Shaded: Part used for the destination

FS-7000/LS-7000

Destination

Europe except France, Asia, South America USA, Canada Japan	Ref. No.	Part code	Description	Remarks
	2C-9	5MVM184NB001	FOOT	
	2C-10	5MMU932SD003	RAIL BOTTOM L	
	2C-11	5MMU932SD004	RAIL BOTTOM R	
	2C-12	5MMM165SN002	ROLLER DU	
	2C-13	5MML332LD002	PLATE FG DRIVE	
	2C-14	5MVX822CB005	RAIL BASE	
	2C-15	5AAVMGNET005	MAGNET CATCHER	
	2C-16	5MMU963SD001	RAIL BASE L	
	2C-17	5MMX952SD003	RAIL MIDDLE	
	2C-18	5MVM177DN007	PULLEY RAIL D	
	2C-19	5MVX222DN002	HOLDER RAIL B	
	2C-20	5MMW661LD003	SPRING RAIL L	
	2C-21	5MVS111PW001	PAD FUSER	
	2C-22			
	2C-23	5MVX432SB012	BRACKET PULLEY B	
	2C-24	5MVM176DN020	PULLEY RAIL B	
	2C-25	5MVB666SB009	DUCT TOP COVER	
	2D-1	5MMX986SD001	PLATE SCAN	
	2D-2	5MMS882SD001	PLATE SCAN MID	
	2D-3	5MML332SD003	PLATE COVER TOP	
	2D-4	5MVB772SB024	DUCT FUSER UP	
	2D-5	5MVB875SB009	DUCT FUSER BOTTOM	
	2D-6	5MVX876CB004	HEAT INSULATER	
	2D-7	5MVX832SB011	RAIL DRUM	
	2D-8	5MMX442LD004	PLATE EARTH SD	
	2D-9	5MVS428DB001	STOPPER DRUM	
	2D-10			

Shaded: Part used for the destination


FS-7000/LS-7000

Destination

Europe except France, Asia, South America USA, Canada Japan	Ref. No.	Part code	Description	Remarks
	2D-11	5AAPRIFC1019AH	P.W.B APCRLK KP-570	
	2D-12	5MMX322LD019	PLATE COVER FUSER B	
	2D-13	5MVS843KF001	SHEET INSULATER A	
	2D-14	5MVL833CB001	HEAT SEPARATOR	
	2D-15	5MVX666SH004	COVER HINGE	
	2D-16	5MVS826FF001	DISCHARGER FU	
	2D-17	5MMS633AX001	SEAL EARTH FU	
	2D-18	5MVS658RF003	SHEET SCAN	

Shaded: Part used for the destination

FS-7000/LS-7000



Destination

Europe except France, Asia, South America USA, Canada Japan	Ref. No.	Part code	Description	Remarks
	3-1	5MMX873SD004	PLATE DRIVE REAR	
	3-2	5MML776SD001	PLATE DRIVE FRONT	
	3-3	5MMU266SD001	PLATE DRIVE MID	
	3-4	5MVG168DN011	GEAR Z72H-Z27H	
	3-5	5MVG158DN017	GEAR Z46H-Z22H	
	3-6	5MVG158DN018	GEAR Z41H	
	3-7	5MVG169DN017	GEAR Z55H	
	3-8	5MVG169DN018	GEAR Z55H-Z27S	
	3-9	5MVG158DN019	GEAR Z45S A	
	3-10	5MVG148DN020	GEAR JOINT Z31S	
	3-11	5MVG169DN019	GEAR Z76H-Z35H	
	3-12	5MMT376LD002	JOINT DRUM	
	3-13	5MMM177CX001	BUSH DRUM JOINT	
	3-14	5MVX441DB001	JOINT DLP	
	3-15	5MMW261LD020	SPRING JOINT UNIT	
	3-16	5MMW161LD031	SPRING EARTH DD	
	3-17	5MMX773SD001	PLATE DRIVE CLUTCH	
	3-18	5MMS767SD004	PLATE COVER GEAR	
	3-19	5MVG169DN020	GEAR Z56H-Z37S	
	3-20	5MVG169DN021	GEAR Z53S-Z23S	
	3-21	5MVG138DN028	GEAR JOINT Z28S	
	3-22	5MVG148DN021	GEAR CLUTCH Z32S	
	3-23	5MVG158DN020	GEAR Z45S B	
	3-24	5MVG159DN008	GEAR Z50S-Z24S	
	3-25	5MVG138DN029	GEAR JOINT Z26S	
	3-26	5MVG138DN030	GEAR Z24S	
	3-27	5MVG158DN022	GEAR Z30S-Z43S-Z17S	
	3-28	5MVC462DN001	HOLDER CLUTCH	
	3-29	5MMW261LD020	SPRING JOINT UNIT	

Shaded: Part used for the destination


FS-7000/LS-7000

Destination

Europe except France, Asia, South America	USA, Canada	Japan	Ref. No.	Part code	Description	Remarks
			3-30	5MVM176DB008	BUSHING STOP	
			3-31	5MMT565SN003	SHAFT CLUTCH F	
			3-32	5EYYALAAK01**01	CLUTCH REGIST	
			3-33	5EYYAFAAM01**01	CLUTCH FEED	
			3-34	5MMX766SD004	PLATE D-CONTAINER	
			3-35	5MVG138DN031	GEAR Z30S-Z20S	
			3-36	5MVG158DN021	GEAR Z45S-Z22S	
			3-37	5MVG048DN003	GEAR Z33S-P36	
			3-38			
			3-39	5MVF182DN001	COVER PULLEY	
			3-40	5MVM190RB023	BELT DRIVE TOWER	
			3-41	5AAPRIFR2006AH	P.W. BOARD ASSY	
			3-42			
			3-43	5AAXMT029GEA	MOTOR MAIN	
			3-44	5MBWK71971NN	FLAT S WASHER	
			3-45	5MBWK81C01NN	FLAT S WASHER	
			3-46	5MBWK01M01NN	FLAT S WASHER	
			3-47	5MVG048DN004	GEAR Z36S-P20	

Shaded: Part used for the destination

FS-7000/LS-7000



Destination

Europe except France, Asia, South America	USA, Canada	Japan	Ref. No.	Part code	Description	Remarks
			4-1	5AAPRLGG4028CH	P.W. BOARD ASSY	Main, KP-536
			4-1	5AAPRLGG4028DH	P.W. BOARD ASSY	Main, KP-536
			4-2	5AAPRCZG4008DH	P.W. BOARD ASSY	Engine, KP-545
			4-2	5AAPRCZG4008EH	P.W. BOARD ASSY	Engine, KP-545
			4-2	5AAPRCZG4008FH	P.W. BOARD ASSY	Engine, KP-545
			4-3	5AAEZ7000E*1	SWITCHING REGULATOR	
			4-3	5AAEZ7000A*1	SWITCHING REGULATOR	
			4-4	5AAPRIFR2005AH	P.W. BOARD ASSY	CON3, KP-568
			4-5	5MMB886SD010	CONT BOX	
			4-6			
			4-7	5MMS636SD009	PLATE OPTION	
			4-8	5MMS646SD009	PLATE CONTROLLER	
			4-9	5MMB876SD002	SHIELD CASE	
			4-10			
			4-11			
			4-12	5MMC765SD001	PLATE CON C	
			4-13	5EZNF2402501*03	FAN MOTOR	Main cont.
			4-14	5EZNF2402501*03	FAN MOTOR	Power supply
			4-15			
			4-16	5MVX743SB008	RAIL OPTION A	
			4-17	5MVX754SB008	RAIL OPTION B	
			4-18	5MVC331NN001	EDGING SADDLE	
			4-19	5MVC441NN001	EDGING SADDLE	
			4-20	5MVX321NN023	LOCKING WIRE SADDLE	
			4-21	5AACCNQA5GEA	CONN CORD ASSY	S02051
			4-22	5AACCNQB7GEA	CONN CORD ASSY	S02063
			4-23	5AACCNQC3GEA	CONN CORD ASSY	S02069
			4-24	5AACCNQK5GEA	CONN CORD ASSY	S02071
			4-24	5AACCNQC5GEA	CONN CORD ASSY	S02071

Shaded: Part used for the destination


FS-7000/LS-7000

Destination

Europe except France, Asia, South America USA, Canada Japan	Ref. No. Part code		Description	Remarks
		4-24 5AACCNQK6GEA	CONN CORD ASSY	S02071
		4-25 5ESC020205***01	SEE-SAW SW	
		4-26 5MVS327RH001	SARCON GR	
		4-27 5MVS552KF007	SHEET CONT D	
		4-28 5MVS872KF006	SHEET CONT A	
		4-29 5MVS652KF005	SHEET CONT B	
		4-30 5MVS332KF003	SHEET CONT C	
		4-31 5MMT263SN012	SCREW OP	
		4-32 5MVVL436WN01	LABEL CAUTION HV	

Shaded: Part used for the destination

FS-7000/LS-7000



04/Controller
 FS-7000/LS-7000
 Jan. 1998
 A=ONE, INC.

Destination

Europe except France, Asia, South America USA, Canada Japan	Ref. No.	Part code	Description	Remarks
		5-1	5MVX997XB001	CASE LOW
		5-2	5MVX321DN010	LATCH RAIL
		5-3	5MVX621DB003	PLATE LOCK A
		5-4		
		5-5	5MVX742SB006	ACTUATOR REGIST
		5-6	5MMW161LD030	SPRING ACTUATOR RE
		5-7	5MMC843SD002	RAIL CASE R
		5-8	5MVM274DN001	PULLEY RAIL C
		5-9	5MMM140SZ009	COLLAR SPACER
		5-10		
		5-11		
		5-12		
		5-13	5MMT876SN050	ROLLER REGIST LOW
		5-14	5MMM121CX001	BUSH DRUM
		5-15	5MVG147DB020	GEAR JOINT Z32
		5-16	5MVS822KF010	SHEET REGIST
		5-17	5MMT876SN049	ROLLER REGIST UP
		5-18	5MMM276CJ001	METAL BUSH REGIST
		5-19	5MVG137DB064	GEAR REGIST Z24
		5-20	5MMW172SD002	SPRING REGIST A
		5-21	5MMW172SD003	SPRING REGIST B
		5-22	5MVX876SC001	GUIDE PAPER
		5-23	5MMW261LD018	SPRING MIDLE
		5-24	5MMT743SN001	SHAFT PULLEY
		5-25	5MVM276DN005	PULLEY MIDDLE
		5-26	5MMT876SN048	ROLLER MIDDLE
		5-27	5MVM276DN006	BUSH B
		5-28	5MVM276DB012	BUSH C
		5-29	5MVM286DB002	LATCH JOINT

Shaded: Part used for the destination

FS-7000/LS-7000

Destination

Europe except France, Asia, South America	USA, Canada	Japan	Ref. No.	Part code	Description	Remarks
			5-30	5MVS868SC001	GUIDE PAPER B	
			5-31	5MMX654LD003	PLATE REGIST	
			5-32	5MMX662LD003	PLATE TC	
			5-33	5MMX662LD004	PLATE DISCHARGER	
			5-34	5MMX644LD004	PLATE EARTH REGIST	
			5-35	5MMU863SD002	PLATE PAPER GUIDE	
			5-36	5MVX822SG001	PLATE RELEASE	
			5-37	5MVX752SG001	HANDLE CASE	
			5-38	5MVB864SB011	GUIDE TC	
			5-39	5MMX321LD024	PLATE CONTACT TC	
			5-40	5MMW354LD003	SPRING TC ROLL	
			5-41	5MMW255LD002	SPRING BUSH	
			5-42	5MVX322DB018	BUSH TRANSFER B	
			5-43	5MMS821LD010	BRUSH DC CHARGE	
			5-44	5MVX822CB004	HOLDER DC CHARGE	
			5-45	5MMT886SN013	ROLLER TRANSFER	
			5-46	5MVX831CB002	GUIDE CHUTE LOW	
			5-47	5MVG138DB062	GEAR TC Z26	
			5-48	5MVX863CB002	GUIDE CHANGE DU	
			5-49	5MVX731DN001	HOLDER RAIL A	
			5-50	5MMW461SD002	SPRING RELEASE B	
			5-51	5MVX421DB011	HOLDER RELEASE	
			5-52	5MMW161SD006	SPRING RELEASE C	
			5-53			
			5-54	5MML962SD001	RAIL CASE L	
			5-55	5MVM276DB013	PULLEY RAIL E	
			5-56	5MVX211SG001	KNOB RELEASE	
			5-57	5MVS118YW002	PAD CUSHION	
			5-58	5MVL752WN04	LABEL CASE A	

Shaded: Part used for the destination


FS-7000/LS-7000

Destination

Europe except France, Asia, South America USA, Canada Japan	Ref. No.	Part code	Description	Remarks
	5-59	5MVVL642WN09	LABEL CASE B	
	5-60	5AAVBRUSH035	BRUSH CLEAN ASSY	
	5-61	5MMS312AX001	SHEET EARTH TC	
	5-62	5MVVL111WN12	LABEL RELEASE A	
	5-63	5MVVL311WN30	LABEL RELEASE B	
	5-64	5MVS612KF009	SHEET GUIDE PAPER A	
	5-65	5MVS622KF005	SHEET GUIDE PAPER B	

Shaded: Part used for the destination

FS-7000/LS-7000



Destination

Europe except France, Asia, South America USA, Canada Japan	Ref. No.	Part code	Description	Remarks
	6-1	5MMT880AX001	ROLLER HEAT	
	6-2	5MVG169XN001	GEAR Z55	
	6-3	5MVM910XN001	BUSH HEAT	
	6-4	5MMW486SJ001	RING STOP	
	6-5	5MMT886SN014	ROLLER PRESS	
	6-6	5MMT876SN051	ROLLER FUSER	
	6-7	5MVG138DN032	GEAR Z29S	
	6-8	5MMM176CJ005	BUSHING SBK	
	6-9	5MVG148XN006	GEAR FUSER Z33	
	6-10	5MVG148XN005	GEAR Z36	
	6-11	5MVG137DB025	GEAR MFEED Z25	
	6-12	5MBELF1060ZZ	BALL BEARING	
	6-13	5MVX222XN002	SEPARATOR	
	6-14	5MVB842KB001	COVER SEPARATOR	
	6-15	5MMW163LD005	SPRING SEPARATOR	
	6-16	5MVB975KB001	FRAME FUSER LOW	
	6-17	5MVB875KB001	FRAME FUSER UP	
	6-18	5MVX865KB001	COVER FUSER	
	6-19	5MMT622SN003	SHAFT EXIT	
	6-20	5MVM176DB010	PULLEY EXIT	
	6-21	5MMW255LD006	SPRING EXIT	
	6-22	5MMZ221LD003		
	6-23	5MVB765KB001	COVER FUSER F	
	6-24	5MVB766KB001	COVER FUSER R	
	6-25	5MVB832KB001	GUIDE ENTRANCE	
	6-26	5MVX665KB001	BKT FUSER	
	6-27	5MVQ511SB003	LINK LOCK	
	6-28	5MVX542DG001	LEVER LOCK F	
	6-29	5MVX542DG002	LEVER LOCK R	

Shaded: Part used for the destination

FS-7000/LS-7000

Destination

Europe except France, Asia, South America	USA, Canada	Japan	Ref. No.	Part code	Description	Remarks
			6-30	5MVX321CG001	LEVER RELEASE	
			6-31	5MMT310SN002	PIN FUSER	
			6-32	5MMW266LD005	SPRING PRESS	
			6-33			
			6-34			
			6-35	5MMX661SD002	PLATE PRESS F	
			6-36	5MMX661SD003	PLATE PRESS R	
			6-37	5MMX631CD001	PLATE FUSER	
			6-38	5MML142CD001	PLUG FUSER	
			6-39	5MMX543LD002	PLATE EARTH	
			6-40	5MMS845LD001	PLATE FUSER UP	
			6-41	5MMX544SD002	PLATE FUSER GEAR	
			6-42	5AAXTM009GEA	THERMISTOR ASSY	
			6-43	5EYFFQ17501Q*01	THERMO STAT 250V 175°C	
			6-44	5EZPB2412120201	HEATER LAMP C	
			6-44	5EZPB1214220201	HEATER LAMP C	
			6-44	5EZPB1015020301	HEATER LAMP C	
			6-45	5EZPB2412120301	HEATER LAMP S	
			6-45	5EZPB1214220301	HEATER LAMP S	
			6-45	5EZPB1015020401	HEATER LAMP S	
			6-46	5MVVL645WN03	LABEL CAUTION FUSER	
			6-47	5MMK116SZ001	NUT FUSER	
			6-48	5MMK116SZ001	NUT FUSER	
			6-49	5MMK116SZ001	NUT FUSER	
			6-50	5AAPRIFC1015AH	P.W. BOARD ASSY	
			6-51	5AACCNQD7GEA	CONN.CORD ASSY	
			6-52	5AACCNQE7GEA	CONN.CORD ASSY	
			6-53	5MVX842KB001	GUIDE CHUTE	
			6-54	5MMB321LD003	SUPPORT SEPARATOR	

Shaded: Part used for the destination


FS-7000/LS-7000

Destination

Europe except France,
Asia, South America
USA, Canada
Japan

Ref. No.	Part code	Description	Remarks
6-55	5MVF111DN005	BUSH SP	
6-56	5MVS421NF001	SHEET FUSER A	
6-57	5MVS211XG001	SHEET FUSER G	
6-58	5MVVL651WN37	LABEL CAUTION L	
6-59	5MBG513060CJ	GROMMET	
6-60	5MVM160XN001	SPACER	
6-61	5MVM160XN001	POLY WASHER	

Shaded: Part used for the destination



Destination

Europe except France, Asia, South America USA, Canada Japan	Ref. No.	Part code	Description	Remarks
	11-1	5MVX976CH001	FRAME RIGHT	
	11-2	5MVX774CH001	FRAME BOTTOM	
	11-3	5MVB863CH001	HOLDER FEED	
	11-4	5MVB852CB002	PLATE BOTTOM	
	11-5	5MVS427XN001	PAD FRICTION	
	11-6	5MML831SL002	SUPPORT BOTTOM	
	11-7	5MVX211DH001	LEVER RETURN	
	11-8	5MVX632SB014	LEVER INTERLOCK	
	11-9	5MMX543LD003	PLATE EARTH MPF	
	11-10	5MML732SL004	PLATE EARTH EF	
	11-11	5MMS657SL016	BKT CLUTCH	
	11-12	5MVG137DN016	GEAR FEED Z22	
	11-13	5MVG138DN026	GEAR MD Z26	
	11-14	5MVG137DN015	GEAR Z22	
	11-15	5MMT766SN005	SHAFT MPF	
	11-16	5MMT866SN023	ROLLER MPF MID	
	11-17	5MVX653CB001	BKT SEPARATOR	
	11-18	5MVB322DN001	CAP CONNECT EF	
	11-19	5MMW361LD012	SPRING SEPARATOR	
	11-20	5MMW471LD001	SPRING BOTTOM	
	11-21	5MMW501LD001	SPRING PULLEY MD	
	11-22	5MVM373DB001	PULLEY S	
	11-23	5MVM176DB012	BUSH POM B	
	11-24	5MVM122DB004	BUSH POM EW	
	11-25	5ENXGP1A73A**01	PHOTO SENSOR	
	11-26	5AAVCLTCH007	CLUTCH ASSY	
	11-27	5AAVROLL*030	ROLLER FEED ASSY	
	11-28	5AAM7000E*01	SEPARATOR ASSY	
	11-29	5EVSZ2401210101	SOLENOID FLAPPER	

Shaded: Part used for the destination

FS-7000/LS-7000

Destination


Europe except France, Asia, South America USA, Canada Japan	Ref. No. Part code		Description	Remarks
	11-30	5MVB542SB001	BKT SENSOR A	
	11-31	5MVX422DB006	ACTUATOR EF	
	11-32	5MMW161LD028	SPRING ACT EF	
	11-33	5MVB642SB010	BKT SENSOR B	
	11-34			
	11-35			
	11-36	5MVX331SB007	ACTUATOR MPF A	
	11-37	5AAPRSSC1017AH	P.W. BOARD ASSY	KP-576/577
	11-38	5MVX311DB010	ACTUATOR MPF B	
	11-39	5MMW161LD027	SPRING ACT MPF	
	11-40			
	11-41	5ESM010242***01	MICRO SWITCH 01X02	
	11-42	5ESP01000101*01	PUSH SWITCH 01 SN	
	11-43			
	11-44			
	11-45			
	11-46			
	11-47			
	11-48			
	11-49			
	11-50	5MVB873CH001	COVER TRAY	Part of 11-65
	11-51	5MVB873CH002	TRAY A	Part of 11-65
	11-52	5MVS871SH001	TRAY B	Part of 11-65
	11-53	5MVS761CH001	TRAY C	Part of 11-65
	11-54	5MVX773SH001	GUIDE PAPAER R	Part of 11-65
	11-55	5MVX773SH002	GUIDE PAPAER L	Part of 11-65
	11-56	5MVH622DH001	ARM TRAY R	Part of 11-65
	11-57	5MVH622DH002	ARM TRAY L	Part of 11-65
	11-58	5MVG127SH003	GEAR MANUAL	Part of 11-65

Shaded: Part used for the destination

FS-7000/LS-7000

Destination					
Europe except France, Asia, South America USA, Canada Japan	Ref. No.	Part code	Description	Remarks	
		11-59 5AAY7000E*53	SENSOR ETON ASSY		
		11-60 5MMX433LD005	STOPPER CAM		
		11-61 5AAPRIFC1009BH	P.W. BOARD ASSY	Env	
		11-62 5AACCNQC8GEA	CONN. CORD ASSY		
		11-63 5AACCNQB9GEA	CONN. CORD ASSY		
		11-64 5MMW501LD002	SPRING PULLEY EF		
		11-65 5AAVTRAY*011	TRAY MPF ASSY		

Shaded: Part used for the destination



Europe except France, Asia, South America USA, Canada Japan	Ref. No.	Part code	Description	Remarks
	12-1	5MVX876SH018	FRAME FD	
	12-2	5MMT865SN008	ROLLER EXIT A	
	12-3	5MMS647SD001	PLATE JOINT FD	
	12-4	5MVM176DB012	BUSH POM B	
	12-5	5MVG148DB010	GEAR FEED Z34	
	12-6	5MVG389RB001	BELT FD	
	12-7	5MVG327DN003	PULLEY P26	
	12-8	5MMX743LD003	PLATE EARTH FD	
	12-9	5ENXGP1A73A**01	PHOTO SENSOR	
	12-10	5MMT266SN003	PIN FD A	
	12-11	5MMT865SN007	ROLLER EXIT B	
	12-12	5MVG138DN033	GEAR Z29S	
	12-13	5MVG148DH001	GEAR IDLE Z33	
	12-14	5MVG148DB009	GEAR IDLE Z40	
	12-15	5MVX443SB003	ACTUATOR FD	
	12-16	5MVX322DB017	ACTUATOR FU	
	12-17	5MMW164LD001	SPRING FD	
	12-18	5MMW153LD003	SPRING FU	
	12-19	5MVG148DB030	GEAR Z38S	
	12-20	5MMW266LD006	SPRING PRESS A	
	12-21	5MVM166AN001	COLLAR	
	12-22	5MVX874SH002	COVER FD	
	12-23	5MVX321SH004	HOLDER FD R	
	12-24	5MVX321SH005	HOLDER FD L	
	12-25	5MVX863CB003	GUIDE CHANGE	
	12-26	5MMW245LD001	SPRING EXIT	
	12-27	5MVM174DB002	PULLEY EXIT	

Shaded: Part used for the destination


FS-7000/LS-7000

Europe except France, Asia, South America USA, Canada Japan			
	Ref. No.	Part code	Description
	12-28	5MVX633SH007	LATCH FD
	12-29	5MMW256LD001	SPRING LATCH
	12-30	5MVX421SB018	ACTUATOR SOL
	12-31	5MMW261LJ032	SPRING SOL
	12-32	5EZSZ240102010	SOLENOID
	12-33	5MVX774SB013	COVER SIDE
	12-34		
	12-35		
	12-36		
	12-37	5MMT733SN004	SHAFT EXIT
	12-38		
	12-39		
	12-40		
	12-41		
	12-42		
	12-43		
	12-44	5MVX331SH001	HOLDER PULLEY
	12-45	5MVX111DB009	PULLEY STOCKER
	12-46	5MVX332SH002	STOCKER
	12-47	5MVX422SH002	BASE STOCKER
	12-48	5MMW605LD003	SPRING STOCKER
	12-49	5MVG138DN036	GEAR Z29S A
	12-50	5MMX331LD001	WASHER WAVE
	12-51	5MMT865SN006	ROLLER EXIT C
	12-52	5MMW143LD001	SPRING PULLEY
	12-53	5MMW245LD002	SPRING EXIT A
	12-54	5MMM121CX001	BUSH DRUM

Shaded: Part used for the destination

FS-7000/LS-7000

Europe except France, Asia, South America USA, Canada Japan			
	Ref. No.	Part code	Description
Remarks			
	12-55	5AACCNQB8GEA	CONN. CORD ASSY S02064
	12-56	5AACCNQF9GEA	CONN. CORD ASSY S02109
	12-57	5MVS526FF001	DISCHARGER FD
	12-58	5MVF111DN005	BUSH SP
	12A-01	5MVX864SH008	GUIDE FD
	12A-02	5MVX332DH001	SNAP
	12A-03		
	12A-04	5MMW453LD001	SPRING FULL
	12A-05		
	12A-06	5MVX532SB006	ACTUATOR FULL
	12A-07	5MMW606LD003	SPRING FD EXIT
	12A-08	5MMS967SD001	PLATE FD
	12A-09	5MMX662LD005	PLATE SWITCH
	12A-10	5AAPRZZC1048AH	P.W.BOARD ASSY



Destinations

Export	Japan	Ref. No.	Part code	Description	Remarks
		20-1	5MMX965SD001	PLATE FEED A	
		20-2	5MMX963SD001	PLATE FEED B	
		20-3	5MMX652SD002	PLATE CONNECTOR	
		20-4	5MVX985SH001	COVER FEED LEFT	
		20-5	5MVX873SH016	COVER FEED RIGHT	
		20-6	5MVX962SH001	COVER FEED FRONT A	
		20-7	5MVX985SH002	COVER FEED	
		20-8	5MVX986SH002	COVER FEED REAR	
		20-9			
		20-10	5MMX973SD002	STAY A-PIN	
		20-11	5MMX952SD001	SRAY B	
		20-12	5MMX855SD001	STAY C	
		20-13	5MMX955SD001	RAIL CASSETTE L	
		20-14			
		20-15	5MMZ885SD001	PLATE FEED DRIVE	
		20-16	5MVX774SN001	COVER FEED DRIVE	
		20-17	5MVG137DN017	FEED GEAR Z24SJ	
		20-18	5MVG158DN023	GEAR FREE Z41S	
		20-19	5MVG148DN022	GEAR Z36S-Z30S	
		20-20	5MVG148DN023	GEAR Z39S	
		20-21	5MVG169DN022	GEAR Z63S	
		20-22	5MVX331CN001	GEAR HOLDER	
		20-23	5MMW261LD021	SPRING JOINT FEED	
		20-24	5MVG132DN002	GEAR FEED Z23S	
		20-25	5MMW261SD003	SPRING NIP FEED	
		20-26	5MMT876SN052	ROLLER NIP FEED	
		20-27	5MVM276DN005	PULLEY MIDDLE	
		20-28			
		20-29	5EZNT2400404*02	DC MOTOR (NIP)	
		20-30	5EZNT2400404*03	DC MOTOR (FEED)	
		20-31	5AAMPS6***02	FOOT	
		20-32	5MMM121CX001	BUSH DRUM	
		20-33	5MMX432LD001	SPRING SHAFT FD	

Shaded: Part is used for the destination.

Destinations


Export	Japan	Ref. No.	Part code	Description	Remarks
		20-34	5MVX962SH002	COVER FEED FRONT B	
		20-35	5MMB972SD001	STAY A RIGHT	
		20-36	5MVX622DN001	ARM COVER	
		20-37	5MVX421DN003	LOCK COVER R	
		20-38	5MMW261SD004	SPRING COVER R	
		20-39	5MMX872SD002	PLATE FEED RIGHT	
		20-40			
		20-41	5MVG148DN027	GEAR Z37S	
		20-42	5MMX732SD001	BKT COVER FRONT	
		20-43	5MMX952SD002	STAY B FRONT	
		20-44	5MVX321DN010	LATCH RAIL	
		20-45			
		20-46	5EZND2400001*01	GEARD MOTOR	
		20-47	5ENXGP1A44E1*01	PHOT SENSOR	
		20-48	5ESP01000101*01	PUSH SWITCH	
		20-49	5ESP01000100*01	PUSH SWITCH	
		20-50	5MVX111DN002	BUSH SP PULLEY	
		20-51	5MVX721SB001	HOLDER CORD	
		20-52	5MVX754SB009	SPACER MOTOR	
		20-53	5MMZ211LD003	PLATE EARTH COVER	
		20-54	5AAVGEAR*028	GEAR NIP ASSY	
		20-55	5AAVPLATE031	RAIL PLATE ASSY	
		20-56	5MMX661SX001	PLATE MOTOR	
		20-57	5MVX531NB004	EDGE CLIP	
		20-58	5MVVSPF30**1	SER. NO. PLATE	
		20-59	5MMM140SZ012	COLLAR SPACER A	
		20-60	5MMM140SZ013	COLLAR SPACER B	
		20-61	5MVS431KF013	SHEET PATH	
		20-62	5MVS816EF001	SHEET RAIL CASS	
		20-63	5MMX221SW002	CORD KEEP	
		20-64	5MMT743LD001	SHAFT NIP PULLEY	
		20-65			
		20-66			

Shaded: Part is used for the destination.

Destinations

Export	Japan	Ref. No.	Part code	Description	Remarks
		20-67			
		20-68			
		20-69			
		20-70			
		20-71			
		20-72			
		20-73			
		20-74			
		20-75			
		20-76			
		20-77			
		20-78			
		20-79			
		20-80	5AACCNQD8GEA	CONN. CORD ASSY	
		20-81	5AACCNQD9GEA	CONN. CORD ASSY	
		20-82	5AACCNQE0GEA	CONN. CORD ASSY	
		20-83	5AACCNQE1GEA	CONN. CORD ASSY	
		20-84	5AACCNQE2GEA	CONN. CORD ASSY	
		20-85	5AACCNQE3GEA	CONN. CORD ASSY	
		20-86	5AACCNQF8GEA	CONN. CORD ASSY	
		20-87	5AAPRCZR2004BH	P.W.B FEED KP-546	

Shaded: Part is used for the destination.



Destinations

Export	Japan	Ref. No.	Part code	Description	Remarks
		21-1	5MVB996SH006	BASE CASSETTE	
		21-2	5MVX882SH001	PLATE BOTTOM	
		21-3	5MML763SW002	GUIDE PAPER SIDE R	
		21-4	5MML765SW001	GUIDE PAPER SIDE L	
		21-5	5MVL666SH002	REAR STOPPER	
		21-6	5MVX863SH006	BKT LIFT BOTTOM	
		21-7	5AAVROLL*032	ROLLER RETARD ASSY	
		21-8	5AAVROLL*033	ROLLER FEED ASSY	
		21-9			
		21-10	5AAVCLTCH008	CLUTCH ASSY	
		21-11	5MMT665SN001	SHAFT RETARD	
		21-12	5MMT864SN006	SHAFT FEED	
		21-13	5MMT864SN007	SHAFT PICK	
		21-14	5MVX521DB002	ACTUATOR SIZE	
		21-15	5MVG147DN014	GEAR Z35S	
		21-16	5MVG147DN012	GEAR Z30	
		21-17	5AAVROLL*031	TORQUE LIMITTER	
		21-18	5MMU752SD002	BKT LIFT PICK	
		21-19	5MMX863SD006	STAY FEED	
		21-20	5MVM276DN009	BUSH RETARD	
		21-21	5MVX731CN001	RACK	
		21-22	5MVX665AC003	HOLDER LED	
		21-23	5MMS756SD008	HOLDER PAPER SIDE R	
		21-24	5MMS756SD009	HOLDER PAPER SIDE L	
		21-25	5MVS522KX001	LABEL SIZE	
		21-26	5MVX642CG002	LEVER LOCK REAR	
		21-27	5MVX642CG001	LEVER LOCK SIDE	
		21-28	5MVS628CN001	ACTUATOR REAR	
		21-29	5MVG127DN045	PINION	
		21-30			
		21-31	5MVM176DN001	PULLEY RAIL CASS	
		21-32	5MML222SD006	BKT RAIL CASS	
		21-33	5MVS637WK001	PAD FRICTION	

Shaded: Part is used for the destination.

Destinations

Export	Japan	Ref. No.	Part code	Description	Remarks
		21-34			
		21-35	5MVX843SH010	LID CASSETTE	
		21-36	5ESZ010201***01	MODE SWITCH	
		21-37			
		21-38	5MMW261SD005	SPRING RACK	
		21-39	5MVX221DN009	SPACER PICK UP	
		21-40	5MVG165DN002	GEAR MODE SW	
		21-41	5MVG147DN013	GEAR Z32	
		21-42			
		21-43	5MMB871SD001	PLATE CASSETTE	
		21-44	5MVX631DB001	ACTUATOR EMPTY	
		21-45	5MMW411LD003	SPRING LEVER	
		21-46	5MVS331KN003	SHEET RETARD	
		21-47	5MMU531LD001	PLATE RETARD	
		21-48	5MVS311RN001	PAD EARTH RAIL	
		21-49	5MMZ331LD002	PLATE EARTH RAIL	
		21-50	5MVX865SX001	COVER CONNECT	
		21-51	5MVX642SX001	COVER PICK UP	
		21-52	5MVVL642WN08	LABEL PICK UP	
		21-53			
		21-54	5MVVL632WN04	LABEL CASSETTE A	
		21-55	5MVVL632WM05	LABEL CASSETTE B	
		21-56	5MVVL431WN13	PAPER LIMIT LABEL	
		21-57	5MMW241SD003	SPRING RETARD L	
		21-58	5MMW241SD004	SPRING RETARD R	
		21-59			
		21-60	5MML821SD005	STAY BOTTOM	
		21-61			
		21-62	5MMW264LD003	SPRING ACTUATOR	
		21-63			
		21-64			
		21-65			
		21-66			

Shaded: Part is used for the destination.

Destinations

Export	Japan	Ref. No.	Part code	Description	Remarks
		21-67			
		21-68			
		21-69			
		21-70			
		21-71			
		21-72			
		21-73			
		21-74			
		21-75			
		21-76			
		21-77			
		21-78			
		21-79			
		21-80	5AACCNQE4GEA	CONN. CORD ASSY	
		21-81	5AACCNQE5GEA	CONN. CORD ASSY	
		21-82	5AACCNQF5GEA	CONN. CORD ASSY	
		21-83	5AACCNQF6GEA	CONN. CORD ASSY	
		21-84	5AAPRSSC1019AH	P.W.B PSIZE KP-581	
		21-85	5AAPRSSC1018AH	P.W.B PICKUP KP-583	
		21-86	5AAPRLDC1002AH	P.W.B LED KP-585	

Shaded: Part is used for the destination.

Destinations

Export	Japan	Ref. No.	Part code	Description	Remarks
		30-1	5MVB886SB008	FRAME MAIN DU	
		30-2	5MMT866SN026	SHAFT L	
		30-3	5MMM121CX001	BUSH DRUM	
		30-4	5MVG1216DN012	PULLEY P18	
		30-5	5AAPRCZR2005AH	P.W.B ASSY	
		30-6	5AAVCLTCH009	CLUTCH ASSY	
		30-7	5MMT876SN053	SHAFT M	
		30-8	5MVG337DN004	PULLEY P24	
		30-9	5MVF182DN001	COVER PULLEY	
		30-10	5MVM190RB020	BELT S2M328	
		30-11	5MMS852LD001	PLATE EARTH A	
		30-12	5MVB865SB040	COVER FRONT DU	
		30-13	5MVM460DB001	ROLLER IDLE	
		30-14	5MMT555SN001	SHAFT B	
		30-15	5MMW155LD001	SPRING BOTTOM	
		30-16	5MVB843SB002	GUIDE PAPER R	
		30-17	5MVB843SB003	GUIDE PAPER L	
		30-18	5MVB822DW001	RACK DU	
		30-19	5MVG147DN010	GEAR Z25-P36	
		30-20	5MVM190RB024	BELT S2M426	
		30-21	5MVB883SB014	FRAME BOTTOM DU	
		30-22			
		30-23	5EYYAFAAM01**02	SPRING CLUTCH	
		30-24	5MVM687DB001	ROLLER GUIDE	
		30-25	5MMT866SN024	SHAFT S	
		30-26	5MMM176CJ003	METAL BUSH KD	
		30-27	5MVM190RB021	BELT S2M 630	
		30-28	5MMM121CX001	BUSH DRUM	
		30-29	5MMM121CX001	BUSH DRUM	
		30-30	5MMM121CX001	BUSH DRUM	
		30-31			
		30-32	5ENXGP1A73A**01	PHOTO SENSOR	
		30-33			

Shaded: Part used for the destination.

Destinations

Export	Japan	Ref. No.	Part code	Description	Remarks
		30-34	5MVB873SB048	PLATE PAPER	
		30-35	5MVB873CC001	PLATE BOTTOM	
		30-36	5MMT876SN053	SHAFT M	
		30-37	5MMM121CX001	BUSH DRUM	
		30-38	5ENXGP1A73A**01	PT. SENSOR	
		30-39	5MVX433DB004	ACTUATOR H	
		30-40	5MVX433DB003	ACTUATOR S	
		30-41	5AACCNQF1GEA	CONN. CORD ASSY S02099	
		30-42	5MVB753SB020	COVER PB	
		30-43	5MVS522KC003	SHEET BU	
		30-44	5MVB886CC001	PLATE TOP	
		30-45	5MVM687DB001	ROLLER GUIDE	
		30-46	5MMW521LX001	SPRING PA	
		30-47	5MVM374DN001	PULLEY PA	
		30-48	5MMT666SN002	SHAFT P	
		30-49	5MVB662DW001	GUIDE TURN	
		30-50	5MMT866SN025	SHAFT PI	
		30-51	5MMT666SN001	SHAFT PU	
		30-52	5MVM190RB019	BELT S2M 124	
		30-53	5AAVR0LL*034	TORQUE LIMITER	
		30-54	5AAVR0LL*036	ROLLER DU ASSY	
		30-55	5AAYDU30**09	ROLLER RETURN ASSY	
		30-56	5MMX776SD003	PLATE DRIVE A	
		30-57	5MMS766SD005	PLATE DRIVE B	
		30-58	5MVG158DN024	GEAR H50-Z36	
		30-59	5MVG148DN024	GEAR Z36-Z29	
		30-60	5MVG148DN025	GEAR Z36-Z24	
		30-61	5MVG137DN020	GEAR Z24	
		30-62	5MVG138DN034	GEAR Z30	
		30-63	5MVG137DN021	GEAR Z30-P30	
		30-64	5MMM121CX001	BUSH DRUM	
		30-65	5MMM176CJ005	BUSHING SBK	
		30-66	5AAXMT031GEA	MAIN MOTOR ASSY	

Shaded: Part used for the destination.

Destinations

Export	Japan	Ref. No.	Part code	Description	Remarks
		30-67	5MVS622SC001	SHEET MO	
		30-68	5MMT466SN001	SHAFT D	
		30-69	5MVG147DN011	GEAR Z36	
		30-70	5MVG148DN026	GEAR CLUTCH Z36	
		30-71	5AAVCLTCH010	ONEWAY CLUTCH	
		30-72	5MVG137DN019	GEAR CLUTCH Z24	
		30-73	5AAVCLTCH010	ONEWAY CLUTCH	
		30-74	5AACCNQE6GEA	CONN. CORD ASSY S02094	
		30-75	5MMS527SD002	BKT CONNECTOR	
		30-76	5MMU932SD001	RAIL CASE L	
		30-77	5MMM165SN002	ROLLER DU	
		30-78	5MMU932SD002	RAIL CASE R	
		30-79	5MMM165SN002	ROLLER DU	
		30-80	5EZA2401020308	SOLENOID	
		30-81	5MMW261LD028	SPRING SOL	
		30-82	5MMS447SD001	BKT SOLENOID	
		30-83	5MVX443SG001	ARM DU	
		30-84	5AAXMT027GEA	STEPPING MOTOR ASSY	
		30-85	5MML373SD006	BKT STEP	
		30-86	5VM176DB014	PULLEY BELT PU	
		30-87	5MML211SN002	PLATE CATCH L	
		30-88	5MML211SN001	PLATE CATCH R	
		30-89	5MVX622SB012	COVER PT	
		30-90	5MVB861SB007	COVER BOTTOM	
		30-91	5MVB864SB013	COVER REAR DU A	
		30-92	5MVB766SB003	COVER REAR DU B	
		30-93	5MVS735CC004	SHEET DU	
		30-94	5AACCNQJ8GEA	CONN CORD ASSY	
		30-95	5AACCNQJ9GEA	CONN CORD ASSY	
		30-96	5AACCNQK0GEA	CONN CORD ASSY	
		30-97	5AAVGEAR*029	GEAR CLUTCH Z36 ASSY	
		30-98	5AAVGEAR*030	GEAR CLUTCH Z24 ASSY	
		30-99			

Shaded: Part used for the destination.

Destinations

Export	Japan	Ref. No.	Part code	Description	Remarks
		30-100	5MMK224FJ001	MAGNET	
		30-101	5AACCNQF2GEA	CONN. CORD ASSY S02100	
		30-102	5AACCNQE3GEA	CONN. CORD ASSY	S02101
		30-103	5MVM150RB008	RUBBER PIN	
		30-104	5MMS426SN003	PLATE MAGNET	
		30-105	5MVS766KN001	SHEET PU	
		30-106	5MML232LD002	PLATE EARTH MANUAL	
		30-107	5MVS845CB001	SHEET TURN	
		30-108	5MMS612LD003	PLATE EARTH DU	
		30-109		SER. NO. PLATE	
		30-110		LABEL FRONT DU	
		30-111	5AAXAP026GEA	P.W.B. MO ASSY	

