

<u>SECTION</u>	<u>TITLE</u>	<u>PAGE</u>
(X) VI	Sol CABINET-CHASSIS ASSEMBLY (Continued)	
6.3	Assembly Tips	VI-1
6.3.1	General	VI-1
6.3.2	Electrical	VI-1
6.3.3	Mechanical	VI-5
6.4	Required Tools, Equipment and Materials . .	VI-6
6.5	Orientation	VI-6
6.5.1	Sol Backplane Board, Sol-BPB	VI-6
6.5.2	Sol Cabinet-Chassis	VI-6
6.6	Assembly-Test	VI-7
6.6.1	Backplane Board (Sol-BPB) Assembly .	VI-7
6.6.2	Wooden-Masonite Parts	VI-8
6.6.3	Sol Assembly	VI-10
() VII	OPERATING PROCEDURES	
() VIII	THEORY OF OPERATION	
(X) IX	SOFTWARE	
9.1	CONSOL	IX-1
9.1.1	DUMp (addr) (addr)	IX-2
9.1.2	ENter addr	IX-2
9.1.3	TLoad (speed)	IX-2
9.1.4	EXecute addr	IX-3
9.1.5	BAsic	IX-3
9.2	Standard I/O Routines	IX-3
(X) X	DRAWINGS	
X-1	Assembly, Fan Closure Plate, Drawing #105014	
X-2	Assembly, Sol-10 & 20 Power Supply, Drawing #105001	
X-3	Sol-PC Assembly Drawing	
X-4	Personality Module Assembly Drawing, PM5204	
X-5	Personality Module Assembly Drawing, PM6834	
X-6	Personality Module Assembly Drawing, PM2708	
X-7	Sol Keyboard Assembly Drawing	