

PROCESSOR TECHNOLOGY CORPORATION

Sol TERMINAL COMPUTERTM

CONTENTS

<u>SECTION</u>	<u>TITLE</u>	<u>PAGE</u>
(X) X	DRAWINGS (Continued)	
	X-8 Side Assembly, Left-hand, Drawing #101007	
	X-9 Side Assembly, Right-hand, Drawing #101008	
	X-10 Assembly, Sol, Drawing #101000 (Sheet 1)	
	X-11 Assembly, Sol, Drawing #101000 (Sheet 2)	
	X-12 Sol-REG Schematic Drawing	
	X-13 Sol-10 Schematic Drawing	
	X-14 Sol-20 Schematic Drawing	
	X-15 Sol CPU and Bus Schematic, Drawing 1	
	X-16 Sol Memory and Decoder Schematic, Drawing 2	
	X-17 Sol Input/Output Schematic, Drawing 3	
	X-18 Sol Display Control Schematic, Drawing 4	
	X-19 Sol Audio Tape I/O Schematic, Drawing 5	
	X-20 Personality Module (PM5204) Schematic	
	X-21 Personality Module (PM6834) Schematic	
	X-22 Personality Module (PM2708) Schematic	
	X-23 Sol Keyboard Schematic	
APPENDICES		
(X)	I Statement of Warranty	
(X)	II 8080 Operating Codes	
(X)	III Standard Color Code	
(X)	IV Loading DIP Devices, Soldering Tips and Installing Augat Pins	
()	V IC Pin Configurations	
(X)	VI TV Interface	
(X)	VII Memory and I/O Allocation Chart	