



## Installing the Ultra100TX2 card on an existing NT 4.0 Operating System

### \*READ THIS FIRST

\*Do not connect any hard drives to the Ultra66 Controller before starting this procedure, connect all drives to your motherboards onboard controller until this install procedure is complete.

### -Install Procedure

- 1.) **Boot Win NT** up to your desktop.
- 2.) Choose "**Settings**" from the "Start Menu".
- 3.) Choose Control Panel from the settings Menu.
- 4.) Double click on "**SCSI Adapters**".
- 5.) Choose drivers and then press "Add".
- 6.) In the Install Driver dialog box, press "**Have Disk**".
- 7.) When the "Install from Disk" appears, insert the "**Ultra100TX2 Driver**" diskette in drive A:, and then choose OK.
- 8.) When the "Install Driver" dialog box appears, select "**Promise Ultra100TX2 Controller NT**" and then press OK.
- 9.) When the "Select SCSI adapter Option appears press "**Install**".

Power down and reconnect drive or drives to the **Promise Ultra100TX2 Controller**. Do not forget to check driver jumpers and BIOS settings. Our controller card is seen as "**SCSI Controller**" by the motherboard BIOS. Make proper changes so you can boot from our controller card.