

8. Exploded Views and Parts List (Basic Model)

8-1. Main Assembly

8-2. Frame Assembly

8-3. MP Assembly


8-4. Fuser Unit Assembly

8-5. RX Driver Unit Assembly


8-6. Cassette Unit Assembly

8-7. SCF(Optional Cassette Unit) Assembly


8.1 Main Assembly




8.2 Frame Unit Assembly




8.3 MP Assembly



8.4 Fuser Unit Assembly



8.5 RX Driver Unit Assembly



8.6 Cassette Unit Assembly

