

3.1 PARTS AND COMPONENTS

Check all parts and components against the "Parts List" on Page III-2 through III-4 (Table 3-1). If you have difficulty in identifying any parts by sight, refer to Figure 3-1 on Page III-5.

3.2 ASSEMBLY TIPS

1. Scan sections III and IV in their entirety before you start to assemble your Sol-PC.

SECTION III

ASSEMBLY

and

TEST

Sol-PC SINGLE BOARD TERMINAL COMPUTER™

