

PROCESSOR TECHNOLOGY CORPORATION

Sol KEYBOARD

SECTION V

<u>LOCATION</u>	<u>VALUE</u>	<u>TYPE</u>	<u>ORIENTATION</u>
() C4	.01 ufd	Disc	None
() C5	.047 ufd	"	"
() C6	.047 ufd	"	"
() C7	.0022 ufd	"	"
() C8	470 pfd	"	"
() C9	220 pfd	"	"
() C10	220 pfd	"	"
() C11	.01 ufd	"	"
() C12	.047 ufd	"	"
() C13	.047 ufd	"	"
() C14	15 ufd	Tantalum	"+" lead top

- () Step 3. Install the following resistors in the indicated locations. Bend leads to fit distance between mounting holes, insert leads, pull down snug to board, solder and trim.

<u>LOCATION</u>	<u>VALUE (ohms)</u>	<u>COLOR CODE</u>
() R1	150	brown-green-brown
() R2	150	" " "
() R3	150	" " "
() R4	68 K	blue-gray-orange
() R5	560 K	green-blue-yellow
() R6	33 K	orange-orange-orange
() R7	1 K	brown-black-red
() R8	1.5K	brown-green-red
() R9	3 K	orange-black-red
() R10	3 K	" " "
() R11	3 K	" " "
() R12	3 K	" " "
() R13	1.5K	brown-green-red
() R14	1.5K	" " "
() R15	1.5K	" " "
() R16	1 K	brown-black-red
() R17	390	orange-white-brown
() R18	1 K	brown-black-red
() R19	10	brown-black-black
() R20	1 K	brown-black-red
() R21	1 K	" " "
() R22	3 K	orange-black-red
() R23	1 K	brown-black-red
() R24	1 K	" " "
() R25	1.5K	brown-green-red
() R26	680	blue-gray-brown
() R27	33 K	orange-orange-orange
() R28	1.5K	brown-green-red
() R29	1.5K	" " "

(Continued on Page V-6.)